

ESW 7010

14 cm high gourmet warming drawer without handle

for preheating crockery, keeping food warm and low temperature cooking.



- The ultimate in enjoyment – low temperature cooking
- Always at the right temperature – 4 functions
- Convenient and easy – Touch control
- Opening the drawer couldn't be easier – Push2open
- Better safe than sorry – timer function with automatic switch-off

EAN: 4002516169734 / Material number: 11093270 /
Old Material Number: 30701030GB

General information	
Model identifier	ESW 7010
Manufacturer material number	11093270
EAN number	4002516169734
Construction type and design	
VitroLine	•
Colour	Graphite grey
ArtLine	•
Handleless	•
Appliance type and design	
Gourmet drawer	•
Programmes	
Cup warming	•
Plate warming	•
Convenience features	
Pre-heating crockery	•
Keeping food warm	•
Perfect cooking results at low temperature	•
Keeping food warm	•
Low temperature cooking	•
User convenience	
Miele@home	•
Control panel with sensor controls	•
Fully telescopic runners	•
Control panel with symbols	•
Push2open	•
Stop programming	•
Timer	•
Sabbath and Yomtov programmes	•
Smart Extras	
Push notifications	•
Recipes	•
Smart Extras	
Alexa voice control	•
Google voice control	•
Smart Home Integration	•
Efficiency	
Power rating in off mode in W	0.3
Power rating in standby mode in W	0.8
Power rating in networked standby in W	2.0
Time until automatic switch to off mode in min	20
Time until automatic switch to standby in min	20
Time until automatic switch to networked standby in min	20
Cleaning and care	
Flush control panel	•
Safety	
Cool front	•
Anti-slip mat	•

ESW 7010

14 cm high gourmet warming drawer without handle

for preheating crockery, keeping food warm and low temperature cooking.



EAN: 4002516169734 / Material number: 11093270 /

Old Material Number: 30701030GB

Safety switch-off

•

Accessory drawer

Capacity 6 place settings

Technical data

Temperatures min. in °C 40

Temperatures max. in °C 85

Appliance width in mm 595

Appliance height in mm 141

Appliance depth in mm 570

Total rated load in kW 0.70

Voltage in V 230

Frequency in Hz 50 - 60

Fuse rating in A 10

Number of phases 1

Useable interior height in mm 80

Mains connection cable with mains plug •

Length of mains connection cable in m 2.0

Accessories included


Anti-slip mat

1


ESW 7010

14 cm high gourmet warming drawer without handle

for preheating crockery, keeping food warm and low temperature cooking.




Installation_DG_DGM_DGC_XL_ESW7x10_EVS7010, installation drawings




Side view_DG_DGM_ESW7x10_EVS7010 installation drawings


A) 22 mm glass, 23,3 mm stainless steel



Installation_DGC_XXL_ESW7x10_EVS7010 installation drawings




built-in ESW7x10 EVS7010, installation drawing




Installation ESW7x10, installation drawing, AU, GB

1) Front view, 2) Mains connection cable, L=2.000 mm, 3) Ventilation cut min. 180 cm², 4) No connection in this area



side view ESW7x10 EVS7010, installation drawing, GB, AU



ESW7010, ESW7110 - installation drawing – Installation – GB, AU

1) Front view, 2) Mains connection cable, L=2,000 mm, 3) ventilation cut-out min. 180 cm², 4) no connection in this area